Wire Rope & Slings

INSPECTION CRITERIA FOR WIRE ROPE SLINGS

Remove slings from service when:

- · Capacity information is missing or illegible;
- End attachments, including hooks, are cracked, deformed or obviously worn;
- Hook throat opening is increased more than 15%;
- Hook is twisted out of plane by more than 10%.

THE DAMAGE: Broken Wires

WHAT TO LOOK FOR: The individual wires that make up the strands in a wire rope can break for various reasons including fatigue and overload. Wire rope slings must be taken out of service when you find 10 or more broken wires in one rope lay or 5 or more broken wires in one strand of one rope lay.

TO PREVENT: Avoid pulling rope across edges or protrusions.



THE DAMAGE: Corrosion / Heat Damage

WHAT TO LOOK FOR: Absence of lubrication and discoloration of rope.

TO PREVENT: Hang slings for storage away from moisture. Do not use wire core slings above 400° F or fiber core slings above 180° F.




THE DAMAGE: Crushing

WHAT TO LOOK FOR: A section of rope that is flattened, where the cross section is no longer round. —

TO PREVENT: Never allow loads to be set on top of slings.

Note: OSHA now requires wire rope slings to have "permanently affixed and legible identification markings"

CAUTION Do not inspect a sling by passing bare hands over the wire rope.



THE DAMAGE: Wear

WHAT TO LOOK FOR: Flat areas on the individual wires. When wires have lost one third or more of their original diameter, the sling must be taken out of service.

TO PREVENT: Do not drag sling on the ground and do not drag loads over slings. Pad high wear areas.



THE DAMAGE: Kinking, Bird Caging

WHAT TO LOOK FOR: Bent strands of wire or strands standing out from their regular position in the body of the sling.

TO PREVENT: Protect rope from sharp edges of load by pads or other means. Do not shock load slings.



For inspection frequency, refer to page 7.